

eGauge Display Caster

[Visit the online store page](#)

Model: EDC



eGauge Display Caster

The eGauge Display Caster provides an easy method display an eGauge meter device interface on a TV or monitor via HDMI through an easy-to-use interface.

The Display Caster has a USB input for power, USB inputs for keyboard and mouse for initial configuration, and an HDMI output to connect to a TV or monitor. Network/internet connection can be obtained through built-in 2.4GHz WiFi or an Ethernet-direct connection.

Once the Display Caster is configured, the saved eGauge device interface will be displayed after automatically recovering from a power outage or communication loss.

Specifications

- USB-C powered*
- USB for keyboard and mouse
- Micro-HDMI to HDMI output*
- 2.4GHz b/g/n

** Versions shipped prior to 2023-08-18 are powered by Micro-USB and have a full-size HDMI port*

Hardware included

- eGauge Display Caster
- USB-C to USB-A for power*
- 120V to USB-C power adapter for power*
- Micro-HDMI to HDMI cable*
- Printed Manual
- Velcro for mounting

** Versions shipped prior to 2023-08-18 include a Micro-USB to USB-A cable, 120V to Micro-USB adapter, and HDMI cable instead*

Assembly/installation information

The default password for the display caster is printed on the paper attached to the manual, as well as inside the box with the eGauge Display Caster. The password can be changed during setup.

Do not leave keyboard/mouse, or USB ports accessible in public kiosk display

1. Connect keyboard and mouse via USB
2. Connect HDMI to television or monitor
3. Apply power using the 120V supply adapter, or USB-to-USB cable

4. Configure network, timezone, and device to display and save as default (see [Display Caster Manual](#) for software setup information).

Software configuration Information

Ensure timezone is set correctly

Ensure default kiosk is saved

Follow the [Display Caster Manual](#) for software setup.

Factory Reset

Connect a keyboard and enter the factory reset code for your version of the display caster. You may need to try multiple key combinations depending on when your display caster was purchased. There is no danger in entering a key combination for a different model.

Current model: `ctrl+shift+f` simultaneously.

Previous model: `shift+escape, f, r, tab` one at a time.

Legacy model: `ctrl+shift+j` simultaneously.

Documents

- [Display Caster Manual \(current version\)](#)
- [Display Caster Manual \(previous version\)](#)
- [Display Caster Manual \(old version\)](#)

Please visit kb.egauge.net for the most up-to-date documentation.