

HomePlug AV Adapter (TRENDnet TPL-406E)

This is a discontinued product. eGauge Systems no longer offers HomePlug-compatible devices. If wireless communication is required, please utilize the [WiFi-enabled EG42xx series meter](#).

The HomePlug AV adapter is used by compatible eGauge models to bring network communication over the existing building power lines. The HomePlug AV adapter plugs directly into a 120V outlet, connects to the router/switch using Ethernet, and allows compatible eGauge models to communicate over the building's electrical wiring.

HomePlug communication is only recommended for residential use, and is not needed when using an alternative communication method, such as Ethernet direct, cellular, or WiFi.

Ensure HomePlug adapter is powered by same phase as eGauge meter L1 connection and is not more than 100 feet of wiring distance from the eGauge meter.

Do not plug HomePlug adapter into surge protector or UPS.

Do not push or hold the button on the HomePlug adapter without full knowledge of pair/reset process. Pushing the button on the HomePlug adapter may result in communication loss.

The HomePlug AV is only for EG301x and EG41xx (Pro/Core Residential). eGauge2 models cannot use this HomePlug. Contact eGauge Support if you are unsure what model you have.



TRENDnet HomePlug AV

Specifications

[Full specs \(data-sheet PDF\)](#)

Hardware included

- HomePlug AV adapter
- 5-foot Ethernet cable

Assembly/installation information

1. Connect the HomePlug adapter to an outlet powered by the same phase as the eGauge L1 near the network router/switch.
2. Connect the Ethernet from the HomePlug adapter to the network router/switch.

3. All HomePlug devices and eGauge meters come with the same default encryption key of "HomePlugAV", and should link up if they have not been modified or paired with the push button pairing process.

Software configuration Information

The HomePlug adapter and eGauge can be paired with a unique encryption key. [See this article for more information.](#)

Documents

- [TPL-406E Datasheet and specifications](#)
- [TPL-406E User Manual](#)

Related Information

- [HomePlug Security Considerations](#)
- [What do the different LEDs on the HomePlug adapter mean?](#)
- [Pairing the eGauge with a HomePlug adapter](#)
- [What are some causes of HomePlug communication issues?](#)
- [Where can I find a HomePlug 1.0 adapter for my eGauge2?](#)

Please visit kb.egauge.net for the most up-to-date documentation.