

# WiFi Access Point (TL-WA801ND)

[Visit the online store page](#)

*Current manufacturer information: TP-Link TL-WA801ND*

The TP-Link WiFi access point allows the eGauge to connect to a 2.4GHz wireless network. It is similar to the [USB-powered WiFi adapter](#) but must be powered off a wall-adaptor and has external antennas.



---

*TP-Link Wifi Access Point*

# Specifications

## [Full specs \(data-sheet PDF\)](#)

- Wireless Standards: IEEE 802.11b/g/n
- Frequency: 2.4GHz
- Wireless Security: 64/128-bit WEP, WPA/WPA2, WPA-PSK/WPA-PSK2

## Hardware included

- TP-Link Access Point
- 2x Antenna
- 1x Ethernet cable
- 1x power supply
- 2x Antenna extension cable
- 1x Velcro mounting strip

## Assembly/installation information

The WiFi access point is powered from a 120V barrel jack and connected to the eGauge via the included Ethernet cable. The access point can be easily mounted inside the powered enclosure kit using an included heavy duty Velcro strip.

## Software configuration Information

[TP-Link access point setup document](#)

## Documents

- [TP-Link TL-WA801ND Datasheet and specs](#)
  - [TP-Link TL-WA801ND User manual](#)
-

# Related Information

- [USB-Powered WiFi adapter](#)
- [Multitech Cellular Modem](#)

---

Please visit [kb.egauge.net](http://kb.egauge.net) for the most up-to-date documentation.