

Defining Views

The eGauge UI displays all registers and virtual registers by default. However, it is possible to define views which show only a subset of all available registers. These views can also be locked so that only individuals with specific credentials can access a given view. This can be useful in submetering applications, or when attempting to simplify the data available on the main graph page. The tutorial video below has additional details.

<https://www.youtube.com/embed/0pzEYuMlwbU?wmode=opaque>

Please visit kb.egauge.net for the most up-to-date documentation.