

How is power factor calculated?

We calculate power factor off of real power (P) and apparent power (S). Where $pf = P/S$. Real power is calculated from the product of the Instantaneous Voltage and Current. Apparent power is calculated from the product of the RMS values for Voltage and Current.

Please visit kb.egauge.net for the most up-to-date documentation.