

# Remote Devices and Third Party Devices

## Overview

The eGauge can record data from a variety of remote devices. This includes other eGauge meters (via UDP over a local network or via TCP through the proxy server) and third party devices via Modbus TCP or Modbus RTU (using a [USB to RS485 converter](#)). Third party devices include any piece of standalone hardware not manufactured by eGauge Systems (ie, anything that's not another eGauge meter).

Data read from remote devices can be displayed through the eGauge user interface, allowing multiple relevant data points to be aggregated in a single location. For example, an eGauge could monitor solar production locally using CTs, then pull additional performance data from the inverter and environmental data from an environmental sensor. Data stored in this way uses register slots on the "master" eGauge meter, meaning there is a limit to how much data can be imported into a single eGauge. For information on database capacity, see [this article](#).

Breaks in communication will result in gaps in the historical data imported by the "master" eGauge meter. These gaps cannot be backfilled or adjusted.

Remote devices are configured under **Settings -> Installation** in the "Remote Devices" section. Best practice is to configure the remote device itself first (eg, ensure the remote device is reporting complete and valid values through that remote device's interface), then configure the "master" eGauge to read data from that remote device.

## Table of Contents

[Example Remote Device Configuration](#)

[Verifying a Remote Device](#)

[Reading from a Remote Device](#)

Supported Protocol Configuration

Remote eGauge via UDP/TCP

Serial

Modbus TCP

ControlByWeb

# Example Remote Device Configuration

The following image shows an eGauge configured to record building consumption using CTs, and recording a solar inverter via Modbus RTU (RS485):

Potential Transformers (PTs):

L1

direct (no PT) ▾

L2

direct (no PT) ▾

L3

direct (no PT) ▾

Sensors:

CTid ⓘ

Use high-gain mode ☐

S1	AE RCT 106mm/4.17" 2775A ▾	x 1	S2	AE RCT 106mm/4.17" 2775A ▾	x 1	S3	AE RCT 106mm/4.17" 2775A ▾	x 1
S4	▾		S5	▾		S6	▾	
S7	▾		S8	▾		S9	▾	
S10	▾		S11	▾		S12	▾	
S13	▾		S14	▾		S15	▾	

Remote Devices:

Modbus Maps

Device name:Protocol:Device address:

Inverterx=Serial▾modbus://CSI-50KTL-GS-B.1@USB2:9600/8n1? ⓘEdit

Add Device

Registers (2 of 64 in use):

Name:Recorded value/formula:

Building Consumptionx=P ▾=S1 ▾xL1 ▾x+S2 ▾xL2 ▾x+S3 ▾xL3 ▾xAdd Component

Inverter AC Powerx=Inverter ▾ActivePower ▾

Add Register

Totals and Virtual Registers:

Usage=+ ▾Building Consumption ▾xAdd Register

Generation=+ ▾Inverter AC Power ▾xAdd Register

There are 3 fields to configure for a remote device:

**Device Name:** This name describes the remote device. In the above example, the remote device is a solar inverter and has been named "Inverter". The name is completely arbitrary, but should make sense to the user.

**Protocol:** The protocol used by the remote device. In the above example, the remote device is using Modbus RTU via an RS485 (serial) connection, and therefore "Serial" is the protocol. A full list of supported protocols is available in the [Supported Protocol Configuration](#) section of this document.

**Device Address:** This describes the remote device and how to communicate with it. The formatting for the device address varies based on the protocol supported by that device, and is explained in detail in the appropriate section for that device:

[Remote eGauge Device Address Format](#)

[Modbus RTU Device Address Format](#)

[Modbus TCP Device Address Format](#)

[ControlByWeb Device Address Format](#)

Device address:

modbus://CSI-50KTL-GS-B.1@USB2:9600/8n1

In the example above, the device address specifies the remote device is using Modbus RTU ( `modbus://` ), the [device map](#) is `CSI-50KTL-GS-B`, with a unit ID of 1 ( `.1` ), is read via a [serial to USB adapter](#) on USB port 2 ( `@USB2` ), uses 9600 baud, 8 data bits, no parity, and 1 stop bit ( `:9600/8n1` ).

## Verifying A Remote Device

After a remote device is configured, the remote device must be verified. To do this, click the grey "?" question mark to the right of the device address field. This will attempt to resolve and read data from the remote device. If this succeeds, the question mark will turn into a green check-mark, indicating the remote device is reachable and returning data.

The blue "i" button to the right of the question mark button will provide debug output after the remote device is resolved. If the remote device fails to resolve, this debug information can help determine why.

The remote device will need to be re-verified every time the Installation page is reloaded.

## Reading From A Remote Device

To actually record data from a remote device, it must first be verified using the process above. Assuming that is successful, create a new register in the "Registers" section by clicking the "Add Register" button. Select a name for the new register. Using the dropdown menu, change the default "P" to the remote device name. A second dropdown menu will appear - select the appropriate register from the list. Make sure to click "Save" at the bottom of the page to save these changes.

Registers (2 of 256 in use):

Name:		Recorded value/formula:
Humidity	x =	Environment Sensor ▾ humidity ▾
Temperature	x =	Environment Sensor ▾ temperature ▾

Add Register

In the example above, the eGauge is set to record two registers from the remote device "Environment Sensor".

## Supported Protocol Configuration

Some protocols are deprecated or unsupported and are not documented here.

### Remote eGauge via UDP/TCP

These protocols are used to have a master eGauge meter read from a secondary eGauge meter. There are two options available - UDP or TCP. This can be used at installations where multiple eGauge meters are present to allow the end user to see a single consolidated view instead of navigating to multiple meters. This protocol is only supported by eGauge meters, and cannot be used with third party devices.

### Remote eGauge Device Address Format

UDP is generally the more stable and reliable option, but only works over local networks where UDP access is available. The Device Address string is simply the [device name](#) of the remote eGauge. An

IP address can also be used, but the meter should either be set to use a [static IP](#) address or assigned a DHCP lease reservation.

TCP uses a connection over TCP port 80 instead of UDP. The Device Address can be a [device name](#) , IP, or FQDN (do not specify "http://" or use any slashes in the address). A TCP connection can be established over the eGauge proxy server, meaning it's possible to pull data from meters at multiple sites into a single master eGauge. However, this connection may be unstable.

Remote devices with site-wide password protection will not allow for remote eGauge via TCP to be used.

The example below shows a master meter configured to read from "eGauge52002" via both UDP and TCP.

Remote Devices:

Modbus Maps

Device name:	Protocol:	Device address:		
TCP Example	remote eGauge via TCP	egauge52002.egaug.es	✓ i	Edit
UDP Example	remote eGauge via UDP	egauge52002	✓ i	Edit

Add Device

# Serial

This protocol is used for devices being read over a serial line. This includes Modbus RTU (both SunSpec and non-SunSpec), SMA and Power-One via serial. Serial data can be read over a local USB port on the EG4xxx using a [USB to RS485 converter](#), or on the EG30xx and EG4xxx meters using [RS485 to Ethernet converter](#) over a local network (LAN).

## Modbus RTU Serial Protocol

The device address for serial devices is as follows:

```
modbus://DEVTYPE.SERIAL_ADDR@CONV_ADDR:PARAMETERS
```

where:

`DEVTYPE` is the device type. This can be the name of a Modbus map. See [this article](#) for information on how to find and create Modbus maps.

`SERIAL_ADDR` is the serial address (also referred to as the slave address, device ID, or unit ID) of the remote device.

`CONV_ADDR` is the address of the serial converter. For USB-serial converters, this can be `USB1` or `USB2` (case-sensitive). If using a serial-to-Ethernet converter, this can be the hostname, MAC address, or IP address of the converter.

`:PARAMETERS` are additional addressing parameters which may be specified.

If using a USB485 converter, the format is `:BAUD/[DATA_BITS][PARITY][STOP_BITS]`. BAUD is the baud, DATABITS is the number of data bits, PARITY is `n` for "none", `e` for "even" or `o` for "odd", and STOP\_BITS are the number of stop bits. Examples include `:9600/8n1` and `:19200/8e1`. It is most typical to have 8 data bits, no parity, and 1 stop bit. If the Modbus map defines default serial parameters, this may be excluded.

If using an Ethernet-serial converter, `:PARAMETERS` specifies a TCP port. If omitted, the eGauge defaults to use port 50,000 which is the default for the support BF-430 converter.

## Examples

```
modbus://imt_si.1@USB1
```

```
modbus://cps403x.5@USB2:9600/8n1
```

```
modbus://ae75_100tx.1@192.168.1.241
```

 Note this is using an IP address to specify a serial-Ethernet converter like the BF-430.

## SMA Serial Protocol

Legacy SMA serial devices may be configured in the format of:

```
sma://@CONV_ADDR
```

where:

`CONV_ADDR` is the address of the serial converter. For USB-serial converters, this can be `USB1` or `USB2` (case-sensitive). If using a serial-to-Ethernet converter, this can be the hostname, MAC address, or IP address of the converter.

## Example

## Remote Devices:

Modbus Maps

Device name:	Protocol:	Device address:	
SMA	Serial	sma://@USB1	<div><div>?</div><div>i</div></div> Edit

Add Device

## Registers (2 of 64 in use):

Name:		Recorded value/formula:
2002260052 AC Power	x =	SMA 2002260052.Pac
2001614686 AC Power	x =	SMA 2001614686.Pac

Add Register

Note: The SMA serial protocol self-defines register names and are prefixed by the serial number of the device being read from. In the above example, "Pac" is the AC Power for the prefixed serial number.

# Power-One Aurora Serial Protocol

Legacy Power-One Aurora serial devices may be configured in the format of:

po://UNIT\_ID@CONV\_ADDR

where:

UNIT\_ID is an optional ID of the inverter being read from. This may be omitted to perform auto-discovery. If auto-discovery fails, please specify the UNIT\_ID in a separate remote device address for each inverter on the serial chain.

CONV\_ADDR is the address of the serial converter. For USB-serial converters, this can be USB1 or USB2 (case-sensitive). If using a serial-to-Ethernet converter, this can be the hostname, MAC address, or IP address of the converter.

## Example

## Remote Devices:

Device name:	Protocol:	Device address:	
InverterA	RS485	po://2@USB1	Edit
InverterB	RS485	po://3@USB1	Edit
InverterC	RS485	po://4@USB1	Edit
Add Device			

## Registers (6 of 64 in use):

Name:	Recorded value/formula:
Inverter A DC V1	InverterA String1_Voltage
Inverter A DC V2	InverterA String2_Voltage
Inverter A RISO	InverterA Isolation_Resistance
Inverter A AC Volt 1	InverterA Grid_Voltage
Inverter B	InverterB Grid_Power
Inverter C	InverterC Grid_Power
Add Register	

# Modbus TCP

Modbus TCP is a protocol that operates over a local TCP/IP network. The remote device must be connected to the same local network as the eGauge.

Using Modbus TCP over the internet (across networks) is unsafe and not supported.

## Modbus TCP Device Address Format

The device address format for Modbus TCP is as follows:

DEVTYPE.UNIT\_ID@ADDR:TCP\_PORT

where:

DEVTYPE is the name of a Modbus map. See [this article](#) for information on how to find and create Modbus maps.



`.UNIT_ID` is the unit ID (also referred to as slave address or device ID) of the Modbus device. If omitted, this defaults to 255. Some Modbus TCP devices do not care what unit ID is specified.

`ADDR` is the address of the Modbus device. This may be an IP, hostname, or FQDN.

`:TCP_PORT` is optional to specify a non-default Modbus TCP port. If omitted, this defaults to the standard Modbus TCP port of 502.

## Examples

`cps403x@192.168.1.242`

---

# ControlByWeb

The eGauge can read from many ControlByWeb products that are network-enabled. This includes the X-320, X-410, X-420 and others. These ControlByWeb devices run a local webserver which the eGauge can read from over the local network. Communication is handled through HTTP requests, meaning only local communication (over the same network) is supported.

## ControlByWeb Device address format

The format for the remote device is simply the IP address of the ControlByWeb device. The ControlByWeb hardware must have a static IP configured or DHCP reservation on the network so the IP address doesn't change unexpectedly.

Device name:	Protocol:	Device address:
<input type="text" value="Control By Web"/>	<input type="text" value="ControlByWeb"/>	<input type="text" value="192.168.1.55"/>
<div><input type="button" value="Add Device"/> <input type="button" value="Done"/></div>		

The following data points are supported. Note that X indicates a there may be multiple data points of that type available (this depends on the model). For example, "countX" could be "count1", "count2", and so on.

- frequency (frequency input)
- vin (voltage powering the CBW device)
- countX (pulse reading)
- analogInputX (analog input value)
- oneWireSensorX (one wire temperature sensors)
- sensorXtemp (temperature sensors)
- extvarX (external variable)
- digitalIOX (binary digital IO value)

Although the eGauge can read from ControlByWeb devices, CBW hardware is not officially supported by eGauge Systems. For configuration questions on the CBW hardware itself, [contact ControlByWeb directly](#).

For questions regarding whether a specific ControlByWeb model is compatible with the eGauge, [contact eGauge support directly](#).

---

Please visit [kb.egauge.net](http://kb.egauge.net) for the most up-to-date documentation.